

Navigation



Owner's Guide to Functions and Benefits GENERAL

Home fire sprinkler systems are designed to:

- 1. Activate quickly once the operating temperature is reached
- 2. Discharge water only from the sprinkler that is activated by fire
- 3. Discharge water at a rate of 50 litres to 100 litres per minute when activated
- 4. Prevent fire within the home becoming a threat to life.
- 5. Allow you and other occupants of your home to escape from the fire.
- 6. In the case of combined systems, uses the same water for fire suppression that comes into the home for normal living use.
- 7. Automatically extinguish or control a fire within a sprinkler protected room.

Home fire sprinkler systems are not designed to:

- Provide early warning to the occupants by means of a water flow alarm (in some cases, it
 will be possible to provide such an alarm, which may be linked into a home security
 system). For this reason, smoke alarms are an integral part of the total life safety system
 within the home.
- 2. Automatically notify the fire service.
- 3. In the case of combined systems, be shut off or shut down separately from the normal domestic water supply.
- 4. Automatically shut the sprinkler water flow off after activation.
- 5. Fully control or extinguish a fire
 - a. which originates in an non-sprinkler protected area before spreading to a sprinkler protected area;
 - b. where combustible material is not the amount or type of material normally found in a home:

- c. where unauthorized changes have been made to the plumbing system after installation; or
- d. when the fire starts under an obstruction such as a desk or work bench.

Areas not covered by the sprinkler system (as per Australian Standards AS2118.5-2008)

- 1. Unattached garages (unless used for sleeping)
- 2. Toilets and bathrooms
- 3. Wardrobes
- 4. Subfloor area
- 5. Ceiling void

This does not mean that sprinklers cannot be fitted into these areas, if required, it would provide additional fire protection.

15 Lerra Road, WINDELLA NSW 2320 | P: **02 4930 9045** F: **02 4930 9046** E: info@resifire.com.au | www.resifire.com.au

ABN: 81 109 886 419 | Contractor Lic: 167289C