

PERMANENT MOUNTING

When it comes to installing a permanent vibrator system, it's important to mount it correctly. This helps to prevent any unnecessary issues in the future, allowing your product to keep flowing as it should.

Thankfully, most vibrators are perfectly easy to mount. In most cases, depending upon the product, this can usually be done from outside the chute.

The simplest method is to use a channel around 500mm long, stitch welded to the hopper wall with no welding at the ends. Positioning of the channel should be such that the vibrator can be mounted about a third the way up from the hopper outlet, so that there is transmission of the majority of the vibration down to the outlet, with some upward into the body of the material. The channel should have a plate attached to carry the vibrator.

Full installation and mounting details are sent with each vibrator, but, feel free to call our team on [08 9209 1163](tel:0892091163) if you have any questions.

